



BEAMZ  
MADE  
EAZY

151.372 V1.3

BTS250C

QUICK **START** GUIDE

# CONTROL MENU

| Menu              |           |                   |                            | Description              |
|-------------------|-----------|-------------------|----------------------------|--------------------------|
| DMX Addr          | d001-d512 |                   |                            | DMX address setting      |
| Mode              | DMX       | 1 / 4 / 6 / 10 Ch |                            | DMX channel mode         |
|                   | Auto      | Program           | 001-005                    | Preset programs          |
|                   |           | Speed             | 001-009                    | Programs speed           |
|                   | Manual    | Red               | 000-255                    | Dimmer 0-100%            |
|                   |           | Green             | 000-255                    |                          |
|                   |           | Blue              | 000-255                    |                          |
|                   |           | White             | 000-255                    |                          |
|                   |           | Strobe            | 000-255                    |                          |
|                   |           |                   |                            | Strobe, slow to fast     |
| Dimmer            | Curve     | 0.3-3.0           |                            | Dimmer curves adjustment |
|                   | Mode      | Standard          | Select dimmer curve        |                          |
|                   |           | Stage             |                            |                          |
|                   |           | TV                |                            |                          |
|                   |           | Architecture      |                            |                          |
|                   |           | Theatre           |                            |                          |
|                   |           | Studio            | Studio power mode - Silent |                          |
|                   |           | Custom            | Fade in (150ms-2230ms)     | Fade out (150ms-2230ms)  |
|                   | Advance   | Authorization     | On / Off                   |                          |
| Signal hold       |           | On / Off          |                            | Run if signal cut        |
| RDM               |           | On / Off          |                            | RDM function on / off    |
| Screen Timeout    |           | 30sec.            |                            | Display shut off time    |
|                   |           | Never             |                            |                          |
| Screen brightness |           | 25-100%           |                            | Display brightness       |
| Dimming Freq      |           | 1.20KHz-24.0KHz   |                            | Dimmer frequency setting |
| Software Version  |           | Vx.xx             |                            | Software version         |
| Reset             | Yes / No  |                   |                            | System reset             |
| Reverse           | Yes / No  |                   |                            | Display reverse 180°     |

# DMX CHANNELS

1 Channel

| Channel | Function | Value   | Description      |
|---------|----------|---------|------------------|
| 1       | Dimmer   | 000-255 | Intensity 0-100% |

4 Channel

| Channel | Function | Value   | Description      |
|---------|----------|---------|------------------|
| 1       | Red      | 000-255 | Intensity 0-100% |
| 2       | Green    | 000-255 | Intensity 0-100% |
| 3       | Blue     | 000-255 | Intensity 0-100% |
| 4       | White    | 000-255 | Intensity 0-100% |

6 Channel

| Channel | Function | Value   | Description          |
|---------|----------|---------|----------------------|
| 1       | Dimmer   | 000-255 | Intensity 0-100%     |
| 2       | Strobe   | 000-013 | No function          |
|         |          | 014-255 | Strobe, slow to fast |
| 3       | Red      | 000-255 | Intensity 0-100%     |
| 4       | Green    | 000-255 | Intensity 0-100%     |
| 5       | Blue     | 000-255 | Intensity 0-100%     |
| 6       | White    | 000-255 | Intensity 0-100%     |

10 Channel

| Channel | Function           | Value   | Description                 |
|---------|--------------------|---------|-----------------------------|
| 1       | Dimmer             | 000-255 | Intensity 0-100%            |
| 2       | Strobe             | 000-013 | No function                 |
|         |                    | 014-255 | Strobe, slow to fast        |
| 3       | Red                | 000-255 | Intensity 0-100%            |
| 4       | Green              | 000-255 | Intensity 0-100%            |
| 5       | Blue               | 000-255 | Intensity 0-100%            |
| 6       | White              | 000-255 | Intensity 0-100%            |
| 7       | Colour temperature | 000-004 | No function                 |
|         |                    | 005-040 | 2800K                       |
|         |                    | 041-076 | 3089K                       |
|         |                    | 077-112 | 3200K                       |
|         |                    | 113-148 | 4200K                       |
|         |                    | 149-184 | 5600K                       |
|         |                    | 185-220 | 7600K                       |
|         |                    | 221-255 | 8000K                       |
| 8       | Colour fading      | 000-004 | No function                 |
|         |                    | 005-255 | Colour fading               |
| 9       | Colour macro       | 000-004 | No function                 |
|         |                    | 005-130 | Colour jump, slow to fast   |
|         |                    | 131-255 | Colour fading, slow to fast |
| 10      | Dimmer mode        | 000-005 | No function                 |
|         |                    | 006-047 | Standard mode               |
|         |                    | 048-089 | Stage mode                  |
|         |                    | 090-131 | TV mode                     |
|         |                    | 132-173 | Architecture mode           |
|         |                    | 174-215 | Theatre mode                |
|         |                    | 216-255 | Custom mode                 |



**European Union**

Tronios B.V.,  
Bedrijvenpark Twente Noord 18,  
7602KR Almelo, The Netherlands

2014/35/EU  
2014/30/EU  
2011/65/EC



**United Kingdom**

Tronios Ltd.,  
130 Harley Street,  
London W1G 7JU, United Kingdom

S.I. 2016:1101  
S.I. 2016:1091  
S.I. 2012:3032





Handwriting practice lines consisting of 25 horizontal dotted lines.



Handwriting practice lines consisting of 20 horizontal dotted lines.



Handwriting practice lines consisting of 25 horizontal dotted lines.



# BEAMZ

**YOUR FUTURE**  
**YOUR SKILLS**  
**YOUR PLATFORM**  
**YOUR PARTY**  
**YOUR EVENT**

 **beamZ<sup>Pro</sup>**

offers a wide range of high performance lighting equipment and related accessories for the rental, entertainment and architectural lighting markets. BeamZ Pro stands for performance, innovation and value pricing!



**BEAMZLIGHTING.COM**